

MAKE: TOYOTA

TYPE: LandCruiser 150 Series
(Prado)

MODEL: KDJ150, GRJ150

YEAR: 2010 on



DETAIL: Station Wagon
SWB & LWB

TOY-100

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>SWB & LWB Petrol</p> <p>Linear Rate Raised Height (40mm Lift)</p>		1		C59-300 (Pair)
<p>Linear Rate Raised Height (40mm Lift) 60-100Kg Accessories (Bull Bar & Winch)</p>		1		C59-302 (Pair)
<p>SWB & LWB Diesel</p> <p>Linear Rate Raised Height (30mm Lift)</p>		1		C59-300 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>		1		C59-350 (Pair)
<p>Linear Rate Raised Height (45mm Lift) 50-100kgs Accessories (Bull Bar & Winch)</p>		1		C59-352 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'G' 'H' 'J'</p> <p>Heavy Duty Gas</p>		J	2	GS59-700

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>SWB</p> <p>Linear Rate Raised Height (20mm Lift)</p>		1		C59-323 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 60-100Kg Accessories</p>		1		C59-325 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 100-300Kg Accessories</p>		1		C59-327 (Pair)
LWB	KDJ150	3.0L T/Diesel		
<p>Linear Rate Standard Height (30mm Lift)</p>		1		C59-325 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>		1		C59-327 (Pair)
<p>Linear Rate Raised Height (30mm Lift) 150-200Kg Accessories</p>		1		C59-327 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		B	2	GS59-701