

MAKE: TOYOTA

TYPE: Landcruiser 200 Series

MODEL: UZJ / URJ /
GRJ / VDJ 200

YEAR: 11/2007 on

DETAIL: Station Wagon



TOY-96

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>GRJ 200 4.0L 6Cyl Petrol</p> <p>Linear Rate Standard Height</p>			2	C59-536 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>			2	C59-540 (Pair)
<p>UZJ 200 4.7L V8 Petrol URJ 200 5.7L V8 Petrol</p> <p>Linear Rate Standard Height</p>			2	C59-538 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>			2	C59-542 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 80-120Kg Accessories</p>			2	C59-544 (Pair)
<p>VDJ 200 4.5L Twin Turbo V8 Diesel</p> <p>Linear Rate Standard Height</p>			2	C59-540 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>			2	C59-544 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 80-120Kg Accessories</p>			2	C59-546 (Pair)
<p>OR</p> <p>Heavy Duty Gas</p>		J	2	GS59-688
<p>Extra Heavy Duty Gas</p>		J	2	GS59-690

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
<p>Linear Rate Standard Height</p>			2	C59-543 (Pair)
<p>Linear Rate Raised Height (50mm Lift)</p>			2	C59-545 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 350Kg to GVM</p>			2	C59-547 (Pair)
<p>Linear Rate Raised Height (50mm Lift) 500Kg to GVM</p>			2	C59-549 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p>				
<p>Heavy Duty Gas</p>		B	2	GS59-682